



PTFGZ-SAL7 FLEX-GUARD® Saloon Door Assembly Instructions

Package contents:

- (1) FLEX-GUARD® Saloon Door panel with all hardware attached to panel
- (2) Mounting Bolts
- (1) 3/16-inch Hex Key for securing Mounting Bolts

Step 1) Open package and review parts to ensure receipt of all pieces. The Saloon Door panels are already secured to the hardware and will be wrapped together in one package. Do not remove the wrapping until the hardware is mounted to the tops of barriers. Assembly is easiest if two people work together assembling on a clean surface.

Step 2) Ensure two barriers are positioned about 3-feet apart. Each top corner of the FLEX-GUARD® barriers have pre-drilled mounting holes for securing the Saloon Door hardware. Locate Mounting Bolts and remove them from packaging.

Step 3) With help, lift and place the Saloon Door bundle on the top corners of the barriers. Align holes in Saloon Door hardware and barriers and insert Mounting Bolts.

Step 4) Finger tighten one end of the Saloon Door hardware and barrier and then do the same for the remaining side. The barrier may need to be moved slightly to ensure proper alignment. Use the provided 3-16-inch Hex Key to fully tighten Mounting Bolts.

Step 5) Remove the wraps from the panels and gently un-roll.

Step 6) Align and connect each end of the Saloon Door panels to the barrier panels with the provided zippered connections.

Step 7) The Saloon Door has now been installed and is ready for use.

Step 8) The Saloon Door comes equipped with interlocks and is pre-wired for the addition of an LED light. Complete any wiring and connections for the interlocks and LED light as needed.

